



TM 215

**Suzuki 9.9 & 15 HP
2014 to Present
Tiller and Remote Shift and Throttle Motors**

TrollMaster is a precision throttle control designed to achieve the maximum in trolling speed accuracy. The memory feature included in this control will allow returning to the best fishing speed time and time again. Whether you are pulling your bait or back trolling, TrollMaster is the answer to your speed control needs. Spend your time trolling, not going to the motor to adjust the speed.

CALL:

1.604.940.2010

EMAIL:

sales@cmpgroup.net

MAIL:

**TROLLMASTER
7733 Progress Way
Delta, British Columbia
Canada V4G 1A3**

FAX:

1.604.952.2650





Instruction for Tiller motors only.

1. Loosen the Tiller Arm tension control knob all the way so the tiller grip can move freely.



2. Remove the engine cowling.






**Instruction for Remote Shift and Throttle motors only
Tiller motors DO NOT need to remove this side cover.**

1. Remove the side cover by removing the screws indicated below.



2. Remove the cowling's rear latch pin and latch.





Instruction for BOTH Tiller and Remote Shift and Throttle motors.

3. Install the first cable mount clip to the orange cable shield. Please note: be sure the orange cable shield is nearly flush with the cable mount clip before squeezing it closed around the cable shield. See photo for example.



4. Add the bolt and four spacers provided in the TrollMaster kit and install as shown.



TROLLMaster™

5. Remove factory bolt and install TrollMaster bolt, spacers and cable as shown below. Please note: The two photos on this page are of the 'Remote Shift and Throttle' version of this motor, not the tiller. This photo is meant to show the cable mount as it should look when installed on both the Tiller and Remote Shift and Throttle motors.



6. Attach cable loop as shown.




TROLLMaster™

- Using the factory bolt, mount the second cable clamp on the bolt identified by the green arrow in the photo.



- Mount the servo bracket as shown using the factory screw and small spacer provided in the TrollMaster kit. Please note: Make sure the small spacer is installed under the servo bracket before tightening screw.



TROLLMaster™

9. Be sure the servo arm is in the position shown in the photos, if it is not, plug the servo into the grey control cable, power the TrollMaster controller ON and leave it in IDLE mode. By removing the Phillips head screw that holds the servo arm on the servo body you can remove the servo arm by pulling it off of the servo body, do not twist and pull, just pull it straight off. Adjust the servo arm to be in the position as shown in the installation manual photos, place the servo arm back on the servo body and return the Phillips head screw to its original location to hold the servo arm in place.

Remove Phillips head set screw from the brass barrel on the servo arm as shown. You will not need the Phillips head set screw in the brass barrel for this install. Run the cable through the brass barrel but do not crimp it yet.



10. With the throttle closed, pull the cable tight to remove any slack, be sure the throttle remains closed. When the cable is tight, slide the crimp over the cable and crimp it tight as shown in the photo. You can then cut off the excess cable.





Instruction for Remote Shift and Throttle motors only.

11. Remove the factory cam by first removing the rod and white rod retainer from the factory cam.



12. Remove the factory cam by removing the bolt; be sure the cam assembly does not come off the motor when removing the bolt.



13. Install the TrollMaster cam and reinstall the factory rod & rod retainer as shown. →





Connecting to a power source:

It is recommended that you install a two-amp fuse on the positive power lead of the PRO and PRO2 models before connecting to a power source. Connect the two amp fused Red wire to +12 volts DC and the Black wire to -12 volts DC. For PRO3 models connect the **RED wire to +12 volts DC** and the **Black wire to -12 volts DC**. PRO3 models come with a thirty (30) amp fuse installed.

Connecting the servo:

Connect the servo cable to the control cable with the brown wire aligned to the white mark on the control cable plug. After the servo is plugged in, move on to set the servo arm.

Set the servo arm:

Power the unit ON and leave the unit in IDLE mode. By removing the Phillips head screw that holds the servo arm on the servo body you can remove the servo arm by pulling it off of the servo body. Adjust the servo arm to be in the position as shown in the installation manual photos and place the servo arm back on the servo body and return the Phillips head screw to its original location to hold the servo arm in place.

Testing the controller:

You do not have to run your outboard motor to test the TrollMaster unit. Test the controller by powering the unit on and press the IDLE button to put the unit into RUN mode. By turning the control knob with a clockwise rotation the servo should move the carburetor from IDLE to FULL THROTTLE.

NOTE: Full throttle can be adjusted by changing the position of the servo arm on the servo motor.



Troubleshooting:

If you should encounter an issue with your TrollMaster use these tips to determine the best course of action to resolve the issue.

Problem: The unit powers on and the display functions properly, your buttons show function on the screen and the numbers increase when turning the speed adjustment knob but there is no response from the servo motor.

Solution: Verify the servo motor is plugged in accordingly with the brown wire aligned with the white mark on the control cable plug and test again. If there is still no response, replace the servo motor with a new one and test again. If after replacing the servo motor and testing again there is still no response contact TrollMaster 1.604.940.2010 to have the unit inspected at our facility.

Problem: The unit powers on works momentarily then powers off. The unit will not stay powered on.

Solution: Check your battery voltage; if the battery voltage is low the unit will not operate properly. When in doubt charge your battery to ensure there is enough voltage to operate the TrollMaster unit to its fullest potential. If the battery is fully charged and the unit is still not operating properly contact TrollMaster 1.604.940.2010 to have the unit inspected at our facility.

If you need assistance with troubleshooting contact us for tech support! Call **1.604.940.2010**



TrollMaster Replacement Parts:

TrollMaster Servo Motor (TM-MG1)

Note: A Servo Arm is included with the purchase of a replacement Servo Motor.

TrollMaster Servo Arm (TM-Servo Arm)

Note: A replacement screw to mount the Servo Arm to the Servo Body is included with the purchase of a replacement Servo Arm.

TrollMaster Hardware Kit (TMXXXHRDWRKIT)

Note: Replace the XXX with the Kit number that applies to your outboard motor. See the Application Guide for kit number. Example: TM206HRDWRKIT.

TrollMaster Electronics Unit Only (TMXXXUNITONLY)

Note: Replace the XXXX with the model of Replacement TrollMaster

Electronics you wish to purchase. Comes with controller and wiring only, does not include servo motor or hardware kit. Examples: TMPROUNITONLY, TMPRO2UNITONLY, TMPRO3UNITONLY.

To Order Replacement Parts:

If you would like to order any of the above mentioned replacement parts check with your local retailer, if they do not have the item in stock they can order it for you or you can order from us directly. For pricing and availability call **1.604.940.2010**

Installation Guides:

The installation Guide on this disk can also be found online at trollmasters.com/installation-guides where you will find the Installation Guides for every motor we make a kit to fit. The Application Guide is also on the same web page; the Application Guide shows the full list of motors we make kits to fit with the product part numbers for those kits.



SERVICE AND WARRANTY

Should your unit ever require service please *do not return the product to your dealer.*

Instead call the number below for special instructions on shipping and handling. Be sure to call between 9 00 AM and 5.00 PM (Pacific Time) Monday through Friday. If the service required is covered by the warranty, it will be repaired or replaced as described below. If the service required is NOT covered by warranty replacement parts are available for purchase and paid for by a major credit card.

The warranty coverage on this equipment is limited to the terms set forth below:

CMP Group LTD. warrants this product to be free of defects in material and workmanship for a period of ONE (1) YEAR from the date of original retail purchase. Positive proof of date of purchase is required for warranty service. If the service required is covered by warranty, you must obtain a **Return Authorization number** from CMP Group . The unit will be repaired or replaced with new or factory rebuilt parts at no charge. The defective components must be returned to the address specified, with shipping charges prepaid. Be sure to include your name, address, telephone number and a copy of the sales receipt showing the date of original retail purchase. All sales receipts are subject to verification.

This warranty does not apply if the unit has been damaged by accident, abuse, misuse, poor installation or misapplication, or if it has been modified from its original condition, or if any serial number has been removed or defaced or altered. This warranty does not cover any expense to remove or reinstall the unit or any of its components. If a returned unit is not covered by warranty, the sender will be notified and given an estimate of the charges to repair or replace the unit together with the return shipping charges.

THIS WARRANTY DOES NOT COVER SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY, OR UNDER ANY OTHER LEGAL THEORY, INCLUDING BUT NOT LIMITED TO DAMAGE TO OR REPLACEMENT OF OTHER EQUIPMENT AND PROPERTY. THE WARRANTY AND REMEDIES SET FORTH ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED. DUE TO THE SPECIAL AND UNIQUE CONDITIONS THAT MAY EXIST IN EACH APPLICATION, THE MANUFACTURER SPECIFICALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. NO DEALER, AGENT OR EMPLOYEE IS AUTHORIZED TO MAKE ANY MODIFICATION, EXTENSION OR ADDITION TO THIS WARRANTY.

Some states do not allow exclusion of incidental or consequential damages, so the above exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other legal rights, which may vary from state to state.

FOR SERVICE CALL: 1.604.940.2010

